


Lap-Shoulder Belt Basics

“Buckle, Check, Tight — Your Seat Belt Is Right!”





Common Seat Belt Parts



BUCKLE

CHECK

TIGHT




BUCKLE the latch plate into the matching buckle after pulling out the shoulder belt webbing from the seatback. **LISTEN** for the **CLICK** sound when the latch plate is fastened!

CHECK that the buckle connection is secure by tugging firmly on the seat belt latch plate.

TIGHTEN the lap portion by pulling upward on the shoulder belt. Be sure that the shoulder belt is snug across the chest and crosses the center of the shoulder.

UNBUCKLING



1. Push the red button on the buckle and remove the latch plate from the buckle.
2. Allow the shoulder belt to retract into the upper seatback so webbing is not loose.

3. As a courtesy to the next passenger, move the shoulder-height adjuster up to its highest position.